

Mighty Bracket™

Innovative support tool makes mini-split installation a single person job.



◆ Clips to the mounting bracket of most mini-split brands, holding the unit securely in place during installation. Will not damage walls.



Mighty Bracket[™]

Code	Description	Qty.	
97705	Mini-split support tool	4	
	FEATURES • Allows single person insta • Simple clip on support • Does not damage walls	ATURES llows single person installation imple clip on support loes not damage walls	

• Folds for easy storage

· Includes tote bag

· Use on most brands of mini-splits



Mini-split installation support tool


APPLICATION • Hook onto mini-split mounting plate to hold mini-split unit securely in place while installing refrigerant lines, condensate line and electrical hookup.

USER INSTRUCTIONS 1. Attach Mounting Hooks of Mighty Bracket to the minisplit mounting plate tabs. (If no tabs are present on the mounting plate, Mighty Bracket hooks can be attached by screws threaded into the wall stud.) 2. Place Foot Supports flat against the wall. (If necessary to avoid potential wall scratching, place clean towel or cardboard between support foot and wall surface) 3. Position Level Adjustment Pins to make Support Arm of the brackets horizontal. 4. Position lift Gates at the end of Support Arms to make sure the unit cannot slide off. 5. Place protective Sleeve Socks over Gates to avoid scratching the unit. 6. Set unit securely onto the top of the Support Arms. 7. Connect refrigerant lines using RectorSeal® NoKink™.*

8. Connect condensate drain piping and electrical wiring. 9. Carefully lift and place the indoor unit onto top tabs of mounting plate. 10. While ensuring unit does not fall, carefully remove Mighty Bracket and installation is complete.

US Patent 9,772,113 Austrtalia Patent AU2014265064 Other patents pending

*When paired with RectorSeal® NoKink™, Mighty Bracket™ allows simple installation without damaging or kinking copper refrigerant lines.



RectorSeal® 2601 Spenwick Drive - Houston, TX 77055 800-231-3345 rectorseal.com RectorSeal Australia Pty Ltd. PO Box 5266 Brendale, Qld 4500 1300 77 2878 rectorseal.com.au